


Walking Treadmill



IMPORTANT: Read all instructions carefully before assembling and/or using this product. Retain this owner's manual for future reference. The specifications of this product may vary from this photo and is subject to change without notice.



PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE.

STOP. Contact customer service if you have any questions regarding assembly or proper operation of the machine.

Email us at:
Service@paradigmhw.com

Or call us at:
1-844-641-7921
Hours:
8:00 am to 5:00 pm (PST)
Monday thru Friday

TABLE OF CONTENT

SERVICE	2
LABEL PLACEMENT	3
IMPORTANT SAFETY GUIDELINES	4
OVERVIEW DRAWING	8
PARTS LIST	9
HARDWARE & TOOL LIST.....	10
ASSEMBLY	11
COMPUTER	16
ADJUSTMENTS	19
MAINTENANCE	20
TROUBLE SHOOTING	21
WARRANTY	22
PARTS REQUEST FORM	23

SERVICE

IMPORTANT: FOR NORTH AMERICA ONLY

For damaged or defective product, questions, replacement parts or any other service support, please contact our customer service department by the below methods:

**For The Best Service, please Email:
service@paradigmhw.com**

Response Time: 1-2 Business Days

Emailing us with the information above will be the best method to receive a response during peak business hours

**Website:
www.paradigmhw.com**

Toll-Free:

1-844-641-7921

(8:00 AM - 5:00 PM Pacific Standard Time, Monday thru Friday)

Response time may vary via calling

Please have the following information ready when requesting for service:

- Your name
- Phone number
- Model number
- Serial number
- Part number
- Proof of Purchase

For damaged or defective product please contact our customer service before returning to the store.

Paradigm Health & Wellness, Inc.

1189 Jellick Ave.

City of Industry, CA 91748, USA

LABEL PLACEMENT

WARNING: Risk of personal injury - Keep children under the age of 13 away from the machine.
ATTENTION: Risque de blessures - Gardez les enfants de moins de 13 ans loin de la machine.
ADVERTENCIA: Riesgo de lesiones personales - Mantenga a los niños bajo la edad de 13 años lejos de la máquina.

Paradigm Health & Wellness, Inc.					
DC:PM	CATALOG LISTING	VOLTS	AMP		
	701027	90	10.5		
H.P. RPM	ROTATION	DUTY	FIELD		
1.25	3300	CW	PM		
		TREADMILL			



EXERWIRK


For customer assistance,
Monday - Friday:
 Pour le service à la clientèle
 composer le, lundi à vendredi:
 Para servicios al cliente,
 llame al, lunes a viernes:

1-844-641-7921
 8 am - 5 pm PST

Paradigm Health & Wellness
 Walking Treadmill
 Caminadora
 Marche Tapis Roulant
 Model: 7905 Date: 01/19
 AC 120V, 60 Hz, 6.5A
FOR HOUSEHOLD USE ONLY
 POUR LA MAISON ATTENTE UTILISATION SEULEMENT
 SÓLO PARA USO DOMÉSTICO

cUL US LISTED
 (MOTORIZED TREADMILL)
 NO:E238026
 11VU

POWER CORD	POWER	
CORDON D'ALIMENTATION	PUISSANCE	FUSE
CABLE DE ALIMENTACIÓN	PODER	
OFF ON		10A



CAUTION: Risk of injury to persons - To Avoid injury, use extreme caution when stepping onto or off of a moving belt. Read Instruction Manual Before Using.
ATTENTION: Risque de blessure pour les personnes - Pour éviter les blessures, soyez extrêmement prudent lorsque vous marchez ou descendez ceinture mobile. Lire le manuel d'instructions avant l'utilisation.
PRECAUTION: Riesgo de lesiones para las personas; para evitar lesiones, tenga extrema precaución al subir o bajar de una correa móvil. Lea el manual de instrucciones antes de usar.

⚠ This Treadmill is Designed for walking only.
Ce tapis roulant est conçu pour la marche seulement.
Esta caminadora fue diseñada solo para caminar.

WARNING: To Reduce the Risk of Electric Shock - Unplug Before Cleaning or Servicing.
AVERTISSEMENT: Pour réduire le risque de choc électrique - Débranchez avant de procéder au nettoyage ou à l'entretien.
ADVERTENCIA: Para reducir el riesgo de descarga eléctrica; Desenchufe antes de limpiar o dar servicio.

CAUTION: To Reduce The Risk Of Injury From Moving - Unplug Before Servicing.
PRECAUTION: Pour réduire le risque de blessure dû au déplacement - Débranchez avant d'effectuer l'entretien.
PRECAUTION: Para reducir el riesgo de lesiones por movimiento; Desenchufe antes de realizar el mantenimiento.

⚠ WARNING
WARNING: CANCER AND REPRODUCTIVE HARM -- WWW.P65WARNINGS.CA.GOV.

⚠

Maximum weight capacity is 325 lbs.
Le poids maximum pour ce produit est 147 kgs.
La capacidad de peso máxima es 147 kg.

IMPORTANT SAFETY GUIDELINES

Basic precautions should always be followed, including the following safety instructions when using this treadmill:

READ ALL GUIDELINES BEFORE USING THIS TREADMILL.

DANGER: To reduce the risk of electric shock, please read the following:

- Always unplug the treadmill from the electrical outlet immediately after using and before cleaning, assembling, or servicing.

NOTE: Failure to follow these instructions may lead to personal injury and cause damage to the treadmill.

WARNING: To reduce the risk of burns, fire, electric shock or injury to any persons, please read the following:

- Never leave the treadmill unattended when plugged in. Disconnect by turning off the master power switch, and unplugging from outlet when not in use and before putting on or taking off parts.
- Use this appliance only for its intended use as described in this manual. **DO NOT** use attachments not recommended by the manufacturer.
- Never operate this treadmill if it has a damaged cord or plug, or if it is not working properly. If it has been dropped or damaged, or been exposed to water, return the appliance to a service center for examination and repair.
- **DO NOT** attempt any maintenance or adjustments other than those described in this manual. Should any problems arise, discontinue use and consult Customer Service.
- Never operate the appliance with the air openings blocked. Keep the air openings free of lint, hair, and the like.
- **DO NOT** use the treadmill outdoors.
- **DO NOT** pull the treadmill by its power cord or use the cord as a handle.
- Keep children and pets away from the equipment while in use. This machine is designed for adults only. This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Keep children under the age of 13 away from this machine.
- **DO NOT** operate where aerosol (spray) products are being used or where oxygen is being administered.

IMPORTANT SAFETY GUIDELINES

- Keep Dry - **DO NOT** operate in a wet or moist condition. Save these instructions.
 - **DO NOT** operate the treadmill near a blanket. Excessive heating can occur and cause fire, electrical shock, or injury to user.
 - Keep electrical cord away from heated surfaces.
 - Never insert any object into any opening.
 - Keep the treadmill on a solid, level surface with the minimum safety area clearance of 2000mm x 1000mm of the treadmill. Be sure the area around the treadmill remains clear during use and has adequate clearance.
 - This treadmill is for household use only.
 - Only **one** person should be on the treadmill while in use.
 - Wear comfortable and suitable clothing when using the treadmill. **DO NOT** use the treadmill barefoot, in only socks or in sandals, always wear athletic shoes. Never wear loose clothing because it could run the risk of getting caught in the treadmill.
 - Always hold on to the handrails while using the treadmill.
 - Always make sure the storage latch is in place when folding and moving the treadmill.
 - **DO NOT** leave children who are under 13 years old unsupervised near or on the treadmill.
 - To disconnect, turn all controls to the off position, then remove plug from outlet.
 - This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they **DO NOT** play with the appliance.
 - Pull up the Safety Tether Key for emergency stop. Reinstall the Safety Tether Key onto the Computer Console. Press the **START/STOP** button to begin exercise again.
 - **Maximum Weight Capacity is 325 lbs / 147 kgs**
 - This treadmill is designed for **WALKING** only.
 - **WARNING: CANCER AND REPRODUCTIVE HARM--WWW.P65WARNINGS.CA.GOV.**
 - **CAUTION:** Risk of Injury to Persons –To Avoid Injury, use extreme caution when stepping onto or off of a moving belt. Read Instruction Manual Before Using.
- NOTE: It is the obligation of the owner to review and explain these safety precautions to all users of this treadmill.**

GROUNDING INSTRUCTIONS


- This product must be grounded. If it should malfunction or break down, grounding provides a path of least resistance for electric current reducing the risk of electric shock.

*** This treadmill is equipped with a cord having equipment grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.**

DANGER: Improper connection of the treadmill grounding conductor can result in the risk of electric shock. Check with a qualified electrician, if you are in doubt as to whether the product is properly grounded. **DO NOT** modify the plug provided with the treadmill. If it will not fit your outlet, have a properly grounded outlet installed by a qualified electrician.

This product is for use on a nominal 120 volt circuit and has a grounding plug that looks like the plug illustrated in sketch A in Figure 1.

Make sure that the product is connected to an outlet having the same configuration as the plug. No adapter should be used with this product.



- This unit must be plugged into a nominal 120 volt outlet which has been grounded.
- Keep hands clear of all moving parts. Never place hands or feet under the Treadmill while in it use.
- **DO NOT** use the treadmill on a carpet that is greater than 1/2 inch in height.
- Before using the treadmill, check that the belt is aligned and centered on the walking deck and all visible fasteners on the treadmill are sufficiently tightened and secure.


IMPORTANT SAFETY GUIDELINES

WARNING: Before beginning any exercise program consult your physician. This is especially important for the persons who are over 35 years old or who have pre-existing health problems. Read all instructions before using any fitness equipment. We assume no responsibility for personal injury or property damage sustained by or through the use of this product. **DO NOT** operate this exercise equipment without properly fitted guards, as the moving parts can present risk of serious injury to young children.

CAUTION: Read all instructions carefully before operating this product. Retain this Owner's Manual for future reference.

SAVE THESE INSTRUCTIONS

OVERVIEW DRAWING



PARTS LIST


Part #	Description	Qty
1	Main Frame	1
2	Front Roller	1
3	Rear Roller	1
4	Walking Belt	1
5	Multi-Slot Belt	1
6	Walking Deck	1
7	Rubber Bumper	6
8	Upper Motor Cover	1
9	Left Rear Cover	1
10	Right Rear Cover	1
11	Side Rail	2
12	Motor 1.25HP	1
13	Bracket	1
14	Power Control Board	1
15	Self-Tapping Phillips Screw 3*12	4
16	Power Control Board Bracket	1
17	Power Socket	1
18	Power Cord	1
19	Overload Protector	1
20	Power Switch	1
21	Wire of Power Control Board	1
22	Wire of Power Socket	1
23	Phillips Screw M5x15	6
24	Flat Head Phillips Screw M5x10	14
25	Spring Washer $\phi 5$	4
26	Inductor	1
27	Outer Hex Bolt M8x25	4
28	Flange Nut M8	4
29	Washer $\phi 8 \times 22 \times 5.0$	4

Part #	Description	Qty
30	Square End Cap Match 25x50xT2.0	2
31	Anti-Loosen Nut M5	4
32	Hex Bolt M8x55	3
33	Flat Head Phillips Screw M6x25	1
34	Self-Tapping Phillips Screw 5x14	8
35	Anti-Loosen Nut M6	8
36	Phillips Screw M6x40	8
37	Flat Washer $\phi 8$	3
38	Wire Clip $\phi 16$	2
39	Rubber Cover	2
40	Wheels $\phi 51 \times \phi 8.5 \times 20$	2
41	Foot Pad	2
42	Flat Washer $\phi 8 \times 22 \times 1.5$	4
43	Spring Washer $\phi 8$	4
44	Hexagon Button Head Screws $\phi 8 \times 40$	2
45	Anti-Loosen Nut M8	2
46	Phillips Screw M3x8	2
47	Flat Washer $\phi 5 \times 15$	2
48	Flat Washer $\phi 5 \times 10$	4
49	Phillips Screw M6x30	6
50	Flat Washer $\phi 6 \times 16$	6
51	PU Cover	1
52	Console	1
53	Safety Tether Key	1
54	Wire Holder	3
55	Upper Signal Wire	1
56	Middle Signal Wire	1
57	Lower Signal Wire	1


HARDWARE & TOOLS PACK



(49) Phillips Screw
6PCS



(50) Flat Washer
6PCS




(23) Phillips Screw
2PCS




(47) Phillips Screw
2PCS



Silicone Oil
1 Bottle




(54) Wire Holder
3PCS





T-type Phillips
Screwdriver

Tool:



**T-type Phillips
Screwdriver**




Step 1

1A. Installing the Left & Right Rear Cover

Slide the **Left Rear Cover (9)** and **Right Rear Cover (10)** onto the rear of the **Main Frame (1)**. Install four **Flat Head Phillips Screws (24)** and fully tighten the hardware with the **T-type Phillips Screwdriver** provided.

ASSEMBLY




Step 2

2A. Mounting the Treadmill to the Desk

Lift up the rear of the **Main Frame (1)** with both hands to allow the **Wheels (40)** to make contact with the ground. Guide the treadmill between the desk legs and carefully lower the **Locking Shafts** of the **Main Frame (1)** into the free slots 2.

Note: Make sure the **Locating Shaft** is locked in to the **Free Slot 2** as shown on **Fig. B**. If **Free Slot 1** is used, the user will step on the motor cover.

ASSEMBLY



Step 3

3A. Installing the Console

Attach the **Console (52)** onto the **Desk** with two **Phillips Screws (23)** and two **Flat Washers (47)**. Tighten the hardware with the **T-type Phillips Screw driver** provided.

3B. Installing the PU Cover

Attach the **PU Cover (51)** onto the Desk with six **Phillips Screws (49)** and six **Flat Washers (50)**. Tighten the hardware with the **T-type Phillips Screw driver** provided.

3C. Installing the Console

Place the **Safety Tether Key (53)** onto the **Console (52)**.

WARNING: ALWAYS CLIP THE SAFETY TETHER KEY TO YOUR CLOTHES BEFORE STARTING THE TREADMILL.


Hardware:



**(49) Phillips Screw
6PCS**



**(50) Flat Washer
6PCS**




**(23) Phillips Screw
2PCS**




**(47) Phillips Screw
2PCS**

ASSEMBLY



Hardware:




(54) Wire Holder
3PCS

Step 4

4A. Connecting the Wires


Adhered the three **Wire Holders (54)** onto the underside of the **Desk Frame**. Clip the **Upper Signal Wire (55)** from the rear of the **Console (52)** into the three **Wire Holders (54)**.



Step 5

5A. Connecting Console and Walking Deck

Connect the **Upper, Middle and Lower Signal Wire (55), (56) and (57)**.



Step

6A. Connecting the Power Cord

Press the “O” symbol on the **Power Switch (20)** down. Plug the **Power Cord (18)** into the **Power Socket (17)**. Firmly press the **Power Cord (18)** all the way in to the **Power Socket (17)**. Plug the other end of the **Power Cord (18)** in to a 110 volt outlet. Press the “I” Symbol on the **Power Switch (20)** to turn power the treadmill.

WARNING: Always turn the power switch to the off “O” position when not in use.

COMPUTER



Flip the Power Switch that is located at the front of the treadmill to the ON position. Before beginning a workout session ensure that the **Safety Tether Key (53)** is properly placed onto the Computer Console and the Safety Clip is securely attached to an article of your clothing. Always stand on the side rails when starting the treadmill, not on the belt.

Quick Start:

Press the **START** at the main screen to begin a workout. The display will do a 3 second countdown before the walking belt starts to move. The initial speed will be 0.4 MPH.

Pause:

During a workout, pressing the **START/PAUSE** button will pause the workout. The display will show **PAUSE** during this time. Press **START** to resume the workout. The display will do a 3 second countdown before the walking belt starts to move.

Emergency Stop:

Pulling out the **Safety Tether Key (53)** will immediately stop the treadmill. Replacing the **Safety Tether Key (53)** on to the console will reset the console.

Lap Tracking:

During the workout, the Main Screen will display the lap progress. The current section of the lap will flash until completed, at which point it will stay solid. Each section represents 0.015 kilometers or 0.01 miles. A complete loop of the track is 0.4 kilometers or 0.25 miles.

Button Functions:

- **START/PAUSE:** Press the START button to start the treadmill, press it again to pause the treadmill.
- **STOP:** Press STOP to stop the treadmill, Press it again to clear the console. Hold the STOP button to reset the console
- **MODE:** Press MODE before starting the treadmill to set a goal option of time, distance, or calories.
- **PROGRAM:** Used to select the training program P1, P2, P3, P4, and P5.
- **UP/DOWN:** Press to increase or decrease the workout goal value of a time, distance, of calorie goal. Press and hold the buttons for the value to change quickly. Press to adjust the speed of the treadmill during a workout
- **SPEED ADJUSTMENT (1 / 2 / 3 / 4):** Press one of the SPEED KEYS 1, 2, 3, 4 on the console to quickly change the speed to the corresponding speed.

Workout Display Statistics:

- **TIME:** Displays your elapsed workout time in minutes and seconds.
- **SPEED:** Displays the current speed from the minimum 0.4 MPH to the maximum 4.0 MPH.
- **DISTANCE:** Displays the cumulative distance traveled during your workout.
- **CALORIES:** Displays the total cumulative calories burned during your workout.

Workout Goal Settings:

TIME GOAL:

1. To set TIME GOAL, press **MODE** until you see the default value of 30 minutes displaying under TIME window.
2. Press **UP** or **DOWN** to change the time. Each time you press **UP** or **DOWN**, the TIME should change in 1-minute increments.
3. The time range is from 5:00 to 99:00 minutes.
4. Press **START** to begin exercising, TIME starts counting down.

DISTANCE GOAL:

1. To set DISTANCE GOAL, press **MODE** until you see the default value of 1 mile displaying under the DISTANCE window.
2. Press **UP** or **DOWN** to change the distance. Each time you press **UP** or **DOWN**, the DISTANCE should change in 0.1 mile increments.
3. The target distance range is from 1.0 to 16 miles.
4. Press the **START** button to begin exercising, DISTANCE starts counting down.

CALORIES GOAL:

1. To set CALORIES GOAL, press **MODE** until you see the default value of 100 displaying under the CALORIES window.
2. Press **UP** or **DOWN** to change the calories. Each time you press **UP** or **DOWN**, the amount of CALORIES should change by 10.
3. The target calories range is from 20 to 1500 calories.
4. Press the **START** button to begin exercising. CALORIES start counting down.

WARNING: ALWAYS CLIP THE SAFETY TETHER KEY TO YOUR CLOTHES BEFORE STARTING THE TREADMILL

Pre-Set Programs:

1. Press the **PROGRAM** button at the main screen to select one of five programs.
2. Keep pressing the **PROGRAM** or **UP/DOWN** buttons to cycle through the training program options.
3. Press the **ENTER** button to select a **PROGRAM** option.
4. The **TIME** window will start flashing to allow for setting a **TIME GOAL**. The time range is from 5:00 to 99:00 minutes. The default **TIME GOAL** period is 30:00 minutes.
5. Press **START** to begin exercising, TIME starts counting down.
6. The speed will change according to the program select. See the table below for the program speed.

P1																				
INTERVAL	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
SPEED (MPH)	0.7	0.7	1.4	1.4	2.0	2.0	2.7	2.7	2.7	2.7	2.7	2.7	2.7	2.7	2.0	2.0	1.4	1.4	0.7	0.7

P2																				
INTERVAL	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
SPEED (MPH)	0.7	1.4	2.0	2.7	3.1	3.1	2.7	2.0	1.4	0.7	0.7	1.4	2.0	2.7	3.1	3.1	2.7	2.0	1.4	0.7

P3																				
INTERVAL	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
SPEED (MPH)	0.7	0.7	0.7	1.4	1.4	1.4	2.0	2.0	2.0	2.7	2.7	2.7	3.1	3.1	3.1	3.1	2.7	2.0	1.1	0.7


P4																				
INTERVAL	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
SPEED (MPH)	0.7	2.0	2.7	3.1	2.7	2.0	0.7	2.0	2.7	3.1	2.7	2.0	0.7	2.0	2.7	3.1	2.7	2.0	1.1	0.7

P5																				
INTERVAL	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
SPEED (MPH)	0.7	2.0	2.7	3.1	4.0	2.7	2.7	3.1	4.0	2.7	2.7	3.1	4.0	2.7	2.7	3.1	4.0	2.7	2.0	0.7

NOTE: If the equipment is left inactive for 5 minutes, The Console will enter Sleep Mode, which happens when there is inactivity for more than five minutes. If the User no activity is detected for more than 30 minutes, the console will auto-shut off.

WARNING: ALWAYS CLIP THE SAFETY TETHER KEY TO YOUR CLOTHES BEFORE STARTING THE TREADMILL

ADJUSTMENTS



Belt Adjustment:


The belt may come loose during transportation and/or stretch after prolonged use. To correct belt issues reference the following situations for the appropriate actions:

1. **Belt is shifting to the LEFT:** turn on the main power switch of treadmill and let the belt run at a speed of 1-1.5 MPH. Using the **6mm Allen Wrench** provided, turn the left rear roller adjustment bolt 1/4 turn in the clockwise direction. You should see the belt start to correct itself by moving back toward the center. Repeat the above procedure until the belt is properly centered.
2. **Belt is shifting to the RIGHT:** turn on the main power switch of treadmill and let the belt run at a speed of 1-1.5 MPH. Using the **6mm Allen Wrench** provided, turn the right rear roller adjustment bolt 1/4 turn in the clockwise direction. You should see the belt start to correct itself by moving back toward the center. Repeat the above procedure until the belt is properly centered.
3. **Belt is jerking or stopping when stepping on it:** Turn off the treadmill. Using the **6mm Allen Wrench** provided, turn both left and right rear roller adjustment bolts 1/4 turn in the clockwise direction. The turns of the adjustment bolt should be the same for the left and right side during this process. Turn on the main power switch of treadmill and let the belt run at a speed of 1-1.5 MPH. While holding on to the handlebars walk on to the treadmill to determine if the belt is still slipping. Repeat the above procedure until the belt no longer slips.

MAINTENANCE

WALKING BELTS & TREADMILL LUBRICANT:

Lubricating the walking board and walking belt is essential as the friction between the two affects the life span and function of the treadmill, therefore it is suggested that the walking board and belt be inspected regularly.



SILICON OIL: The treadmill has been coated with Silicone Oil during construction. **Silicone oil is a non-volatile oil.**

To maintain the belt, "Silicone Oil" may be re-applied once the resistance has been increased and the belt starts rubbing against the walking deck. To re-apply the Silicone Oil to the treadmill, lift up the belt, one side at a time, and apply the oil directly to the center of the walking deck. Allow the silicone oil to 'set' for one minute before using the treadmill.

ATTENTION: Only use "Silicone Oil" lubricants for this equipment. **In addition, do not add any other type of oil; otherwise the treadmill will be damaged. Do not over-lubricate the walking board. Excess lubricant should be wiped off with a clean towel.**

WARNING: To prevent electrical shock, turn off and unplug the treadmill before cleaning or performing routine maintenance.

CLEANING: The treadmill should be cleaned with a soft cloth and mild detergent. Do not use abrasives or solvents. Be careful not get excessive moisture on the display panel as this will cause an electrical hazard or the electronics to fail. Keep the treadmill, especially, the console, out of direct sunlight to prevent screen damage and paint discoloration.

STORAGE: Store the treadmill in a clean and dry environment. Ensure the master power switch is off and is in the off position and the power plug is un-plugged from the electrical wall outlet.

TROUBLESHOOTING

Error Codes Cause and Solutions

Fault Code	Cause	Solution
ATTACH SAFETY KEY	Safety tether key protection	<ol style="list-style-type: none"> 1. Ensure that the Safety Tether Key is installed on the Console. 2. Restart the power after 1 minute and install the Safety Tether Key 3. Computer IC Board damaged, Contact Customer Service.
Er1	Computer receiving error signal up to 15 seconds.	<ol style="list-style-type: none"> 1. Restart the power, and retry after 1 minute 2. Ensure the sensor cable is connected perfectly 3. Signal cable or computer IC board damaged, Discontinue use and contact Customer Service
Er3	Low Voltage	<ol style="list-style-type: none"> 1. Restart the power and retry after 1 minute. Check if the input voltage is lower. Use when voltage is normal 2. Signal Cable or power IC board damaged, Discontinue use and contact Customer Service
Er5	<ol style="list-style-type: none"> 1. Motor Cable become loose 2. Motor is blocked 3. Motor damaged 	<ol style="list-style-type: none"> 1. Restart the power, and retry after 1 minute 2. Check the motor cable , make sure it is connect perfectly 3. Check the motor quality, make sure there is no visible damage. 4. Ensure the walking belt is thoroughly lubricated. 5. Motor or power IC board damaged, Discontinue use and contact Customer Service
Er7	Power IC board not receiving signal	<ol style="list-style-type: none"> 1. Restart the power, and retry after 1 minute 2. Ensure that the sensor cable is connected perfectly 3. Signal cable or power IC board damaged, Discontinue use and contact Customer Service

WARRANTY

MANUFACTURER'S LIMITED WARRANTY

Paradigm Health & Wellness warrants to the original purchaser that this product is free from defects in material and workmanship when used for the purpose intended, under the conditions that it has been installed and operated in accordance with Paradigm's Owner's Manual. Paradigm's obligation under this warranty applies to the following:

<u>COMPONENT</u>	<u>LENGTH OF WARRANTY</u>
-------------------------	----------------------------------

Structural Frame	3 year For Home Use Only
-------------------------	---------------------------------

Motor	5 years For Home Use Only
--------------	----------------------------------

All Other Components	90 days For Home Use Only
-----------------------------	----------------------------------

(computer display, electronics, upholstery, foam, ball bearings, pulleys, belts, cables, wires, shocks, covers, tension, internal mechanism, wheels, pedals, knobs, accessories and hardware)

Exclusions from Warranty Coverage:

Paradigm does not warrant against and is not responsible for, and no implied warranty shall be deemed to cover, any product failure, product malfunction, or damages attributable to:

1. Improper installation and/or failure to abide by Paradigm's installation guidelines;
2. Use of this product beyond normal home use, or in an application for which it was not designed;
3. Cosmetic items such as scratches, dents or discolorations;
4. Damage caused by normal wear and tear, vandalism, accidental or by animals;
5. Any act of Nature (such as fire, flooding, snow, ice, hurricane, earthquake, lightning or other natural disaster), environmental condition (such as air pollution, mold, mildew, etc.), or staining from foreign substances (such as dirt, grease, oil, etc.);
6. Normal weathering due to exposure to sunlight, weather and atmosphere which can cause colored surfaces to, among other things, flake, chalk, accumulate dirt or stains.
7. Improper operation, alteration, handling, storage, abuse or neglect of the products.

Paradigm, using its sole discretion, will either repair or replace free of charge any part(s) proven to be defective under normal home use. Any repair or replacement shall provide no new warranty coverage, but shall retain only the remaining portion of the original product's warranty. This warranty is offered only to the original purchaser and is not transferable. Proof of original purchase is required.

Ordering Replacement Parts

Replacement parts can be ordered by emailing our customer service department:

Service@paradigmhw.com

Open Monday Thru Friday 8:00 AM - 5:00 PM (PST).

When ordering replacement parts please have the following information ready:

- 1. Owner's Manual**
- 2. Model Number**
- 3. Description of Parts**
- 4. Part Number**
- 5. Date of Purchase**

PARTS REQUEST FORM

Paradigm Health & Wellness, Inc.

EMAIL THIS FORM WITH YOUR RECEIPT OF PURCHASE TO

Service@paradigmhw.com *

NAME: _____

ADDRESS: _____

CITY: _____ STATE: _____ ZIP: _____

TELEPHONE: (Day) _____

(Night) _____

SERIAL#: _____

MODEL#: _____

PURCHASE DATE: _____

PLACE OF PURCHASE: _____

PART #	DESCRIPTION	QTY

"YOUR ORDER WILL BE PROCESSED WITHIN 3 BUSINESS DAYS"

**** This form can also be faxed in Fax #: 626-810-2166***