OWNER'S MANUAL

IRONMAN FITNESS

TRIATHLON









Triathlon X-Class 610
Smart Technology Elliptical Trainer with Bluetooth

Model 6371

The specifications of this product may vary from this photo and are subject to change without notice.
IRONMAN, IRONMAN TRIATHLON and M-DOT are registered trademarks of World Triathlon Corporation.
This product is licensed by the World Triathlon Corporation.

TABLE CONTENT

SERVICE ---------- 4

LABEL PLACEMENT ---------- 5

PRODUCT SAFETY ---------- 6

OVERVIEW DRAWING ---------- 7

PARTS LIST ---------- 9

BOX CONTENTS ---------- 11

ASSEMBLY ---------- 13

COMPUTER ---------- 23

HEART RATE CHEST BELT---------- 31

TROUBLE SHOOTING & MAINTENANCE ---------- 32

WARM UP ---------- 33

WARRANTY ---------- 34

FAX FORM ---------- 35

IMPORTANT: FOR NORTH AMERICA ONLY

For best product service, please email us at: Service@paradigmhw.com

Response Time: 1-2 Business Days

Or call us toll free at 1-844-641-7922
Daily 8:00 AM-5:00 PM Pacific Standard Time
Response time may vary


Please have the following information ready when requesting service:

Your name
Phone number
Model number
Serial number
Part number
Proof of Purchase

Before returning this product to the store please contact customer service.

Paradigm Health & Wellness, Inc.
1189 Jellick Ave
City of Industry, CA 91748 USA
www.paradigmhw.com.

LABEL PLACEMENT




Basic precautions should always be followed, including the following safety instructions when using this equipment. Read all instructions before using this equipment.

1. Read all the instructions in this manual and do warm up exercises before using this equipment.
2. Before exercising and to avoid injuring your muscles, perform warm-up exercise for each muscle group is highly recommended. Please refer to Warm Up section of the Owner's Manual.
3. Please make sure all components are not damaged and in working order before use. This equipment should be placed on a flat surface while in use. Using a mat or other material on the ground is recommended.
4. Please wear proper clothes and shoes when using this equipment; do not wear clothes that might catch in any part of the equipment.
5. Do not attempt any maintenance or adjustments other than those described in this manual. Should any problems arise, discontinue use and consult with customer service at Paradigm.
6. Caution should be taken when getting on or off the equipment. To get on, make sure the left foot pedal is at the lowest position. Grab the stationary handlebar firmly with both hands then place your left foot onto the left foot pedal. Once your left foot is secured, place your right foot onto the right foot pedal. To begin exercising, push/pull on the handrails first and then follow with leg motion. To get off, come to a complete stop and do the above in reverse.
7. Keep dry - do not operate in wet or moist condition.
8. Do not use the equipment outdoors.
9. This equipment is for household use only.
10. Only one person should be on the equipment at any time.
11. Keep children and pets away from the product while in use.
12. This machine is designed for adults only.
13. This product requires a minimum of 6 feet of space for safe operation.
14. If you feel any chest pains, nausea, dizziness, or shortness of breath, you should stop exercising immediately and consult your physician before continuing.
15. **The maximum weight capacity for this product is 325 lbs /147 kgs.**


WARNING: Before beginning any exercise program consult your physician. This is especially important for the people who are over 35 years old or who have pre-existing health problems. Read all instructions before using any fitness equipment.

CAUTION: Read all instructions carefully before operating this product. Retain this Owner's Manual for future reference.

OVERVIEW DRAWING



OVERVIEW DRAWING




PARTS LIST

No	Description	Qty	No	Description	Qty
A01	Welded, Main Frame	1	B19	Bolt M8	2
A02	Welded, Upright Post	1	B20	Bolt 3/8"	2
A03	Welded, Handrail Arm /Left	1	B21	Washer 3/8"	4
A04	Welded, Handrail Arm /Right	1	B22	Dome Nut 3/8"	2
A05	Welded, Foot Pedal Tube /Left	1	B23	Screw M6	8
A06	Welded, Foot Pedal Tube /Right	1	B24	Bolt M8	2
A07	Welded, Rotate Tube /Left	1	B25	Nut M8	1
A08	Welded, Rotate Tube /Right	1	B26	Nylon Nut M10	3
A09	Welded, Front Stabilizer Tube	1	B27	C-ring ø17	1
A10	Welded, Shaft Pulley	1	B28	Carriage Bolt M8	4
A11	Welded, Crank Assembly	2	B29	Nylon Nut M8	12
A12	Tube, U Shape Guide Rail	1	B30	Curve Washer M8	12
A13	Handlebar /Left	1	B31	Shaft ø20	2
A14	Handlebar /Right	1	B32	Bolt M8	6
A15	Welded, Tension Wheel Arm	1	B33	Washer 5/16"	6
A16	Stationary Handlebar	1	B34	Bolt M10	2
A17	U Shape Bracket	2	B35	Bolt M8	4
A18	Rotate Bar Connect Bracket	2	B36	Screw M3	4
A19	Side Plate of Foot Pedal Tube	2	B37	Screw 3/16"	1
B01	Bolt 1/4"	2	B38	Screw M3	2
B02	Washer 1/4"	4	B39	Screw M4	6
B03	Nut 1/4"	2	B40	Screw M5	37
B04	Nut M10 (8.0T)	1	B41	Screw M8	2
B05	Nut M10 (6.0T)	1	B42	Bushing Spacer	2
B06	C-ring ø20	3	B43	Zinc Plate	2
B07	Wave Washer M21	6	B44	Bolt M8	4
B08	Washer M20	1	B45	Phillip Round head Screw M5	2
B09	Screw 3/16"	2	B46	Bolt M8	4
B10	Bolt M8	1	B47	Plastic Washer ø 20	2
B11	Bolt M10	1	B48	Spring Washer M10	2
B12	Bolt M12	2	B49	Bolt M8	2
B13	Bolt M8	6	B50	Tooth Lock Washer AW ø8	4
B14	Washer 1/2"	6	B51	Bushing Spacer	4
B15	Nut M12	2	B52	Washer 5/16"	4
B16	Bolt M8	2	C01	Main Cover /R	1
B17	Screws for Computer	4	C02	Main Cover /L	1
B18	Shaft ∅19	2	C03	Disc Cover	2


PARTS LIST

No	Description	Qty	No	Description	Qty
C04	End Cap	4	C26	Washer ø14	4
C05	Foot Pad -A	4	C27	Bottle Holder	1
C06	Wheel	2	C28	End Cap	4
C07	Post Cover Left	1	C29	Washer ø20.5	2
C08	Post Cover Right	1	C30	End Cap	2
C09	End Cap	4	D01	Hand Pulse Sensor	1Set
C10	Belt	1	D02	Computer	1
C11	Nut Cap M8	6	D03	Magnetic Flywheel	1
C12	Foot Pedal	2	D04	Upper Cable	1
C13	Foam Grip	2	D05	Lower Cable	1
C14	Cushion Pad	2	D06	Motor	1
C15	Foam Grip	2	D07	Sensor Cable	1
C16	End Cap	2	D08	AC Adaptor	1
C17	Handlebar Cover A	2	D09	AC Plug Cable	1
C18	Handlebar Cover B	2	D10	Hand Pulse Cable	1Set
C19	Pulley	1	D11	Motor Tension Cable	1
C20	Roller	2	E01	Bearing 6004	14
C21	Foot Pad -B	2	E02	Bearing 6003	4
C22	Washer ø17	4	E03	Bearing 6001	4
C23	Upright Post Spacer	2	E04	Bearing 6203	2
C24	Crank Cover	2	E05	Bearing 5104	2
C25	Bushing Ø33.4	4	F01	Aluminum Rail	2

BOX A



(A01) Main Frame
1 SET



(A12) U Shape Guide Rail
1 SET



(A16) Stationary Handlebar
1 SET




(D02) Computer
1 PCS



Lubricant
1 PCS



(D08)Adapter
1 PCS



(A09) Front Stabilizer
1 SET




(A02) Upright Post
1 SET



(C27) Water Bottle Holder
1 PCS



(C07/C08) Upright Post Decorative Cover
1 SET




(C17/C18) Handrail Arm Decorative Cover-A/B
2 SET

BOX B




(A03/A04) Handrail Arm L/R
2 SETS




(A13/A14) Handlebar L/R
2 PCS



(C11) Nut Cap M8
4 PCS



(A05/A07) Foot Pedal Tube/L
Rotate Tube/L
1 SET



(A06/08) Foot Pedal Tube/R
Rotate Tube/R
1 SET



(C14) Cushion Pad
2 PCS



(C12) Foot Pedal
2 PCS

BOX B CONTAINS HARDWARE & TOOLS




(B44) Bolt M8x20mm
4PC



(B33)Washer 5/16"x30x2.0T
4PC




(B41)Screw M8x25mm
2PC



(B32)Hexagon Head Bolt
M8x16mm
4PC



(B29) Nylon Nut M8x7.7T
4PC




(B30)Curve Washer
M8x20x1.5T
4PC



(B28)Bolt M8x50mm
4PC



(B40)Screw M5x16mm
10PC



(T01) Hex Tool Phillips Screwdriver
(13mm/14mm)
1PC



(T02) Allen Wrench (M6)
1PC




(T03) Allen Wrench (M5)
1PC

1. Remove Front Protection Bar

Place a Styrofoam Block under the Main Frame (A01) for easier removal of the Front Protection Bar.This bar may be discarded.

Loosen the Dome Nuts (B22) first and then the Bolts (B20) and Washers (B21) with the Hex Tool (T01) provided. Keep these for the next step. Remove the front protection bar from the Main Frame.




Tool:



(T01)Hex Tool with Phillips Screwdriver
(13mm/14mm)

2. Front Stabilizer Installation

Attach the Front Stabilizer (A09) onto the curve plate of the Main Frame (A01) and align the bolt holes with 2 Bolts (B20), 4 Washers (B21)and 2 Dome Nuts (B22).Tighten bolts with the Hex Tool (T01) provided.




Tool:



(T01)Hex Tool with Phillips Screwdriver
(13mm/14mm)

Hardware:



(B20) Bolt 3/8”x64mm 2PC



(B21)Washer3/8”x20x2.0T 4 PCS





(B22)Dome Nut 3/8”X17T 2PC

3. U Shape Guide Rail Installation

Remove 6 Curve Washers M8 (B30) and 6 Bolts M8 (B13) from the Main Frame (A01) and use them to install the U Shape Guide Rail (A12) onto the 3 tubes of the Main Frame.

IMPORTANT: After A12 is installed, tighten Bolts (B49) on the Aluminum Rail (F01).






(T03)Allen Wrench (M5) 1 PCS


4. Upright Post Installation


This assembly step requires 2 people.

Lift up the Upright Post (A02) and connect the wires (D04/D05),then **gently** tuck the excess wire into the Upright Post (A02) and Main Frame (A01).


Assemble the Upright Post (A02) with 4 Bolts (B44) and **hand tighten** them to ensure proper hole alignment. After all 4 bolts are in, secure them with the Hex Tool (T01) Provided.







(T01)Hex Tool with Phillips Screwdriver




(B44) Bolt M8x20mm
4PC

5. Lubricating the Horizontal Axle and Crank Axle

Apply some lubricant onto both horizontal axles of the Upright Post (A02) and both axles of the Crank (A11).

Remark: Gently apply lubricant evenly on Upright Post (A02). Brush tool is recommended.






Lubricant

6.Handrail Arm Installation

Insert the Right Handrail Arm (A04) all the way onto the horizontal axle of Upright Post (A02) and secure the Right Handrail Arm (A04) in position with 1 Hexagon Head Bolt M8 (B32) and 1 Washer 5/16" (B33).

Repeat for the left side




(T01) Hex Tool with Phillips Screwdriver



(B32) Hexagon Head Bolt M8



(B33) Washer 5/16" x30x2.0T





7. Pedal Installation

Remove the 4 Screws (B23) from the Right Foot Pedal Tube (A06).
Install Foot Pedal (C12) with the removed screws.

Attach the Cushion Pad onto the Foot Pedal.

Repeat this step for the left side






(T01)Hex Tool with Phillips Screwdriver


8. Tube Assembly

Place the Right Rotate Tube (A08) onto the Aluminum Rail (F01). Insert the Right Rotate Tube onto the axle of Crank (A11) and secure the Bolt (B32) and Washer (B33) using the Hex Tool (T01). Attach Nut Cap (C11).

Repeat this step for the left side



(T01)Hex Tool with Phillips Screwdriver





(B32) Hexagon Head Bolt M8
2PCS




(B33) Washer 5/16”x30x2.0T

9. Handrail Arm Assembly


Remove Bolt (B24), Washer (B52) and Nut (B29) from the Right Handrail Arm (A04)


Put the Right Handrail Arm onto the Right Foot Pedal Tube (A06). Install with the previously removed hardware by inserting the Allen Wrench into the Bolt (B24) and tightening the Nut (B29) with the Tools (T01/T02). Attach the Nut Cap (C11).

Repeat this step for the left side.



Important: *Remove twist ties and ensure that Washers (C22) are in place before assembly!*





(T01)Hex Tool with Phillips Screwdriver





(T02)Allen Wrench (M6)

10. Stationary Handlebar Installation

Carefully, route both cables from Upright Post (A02) through the square hole of Stationary Handlebar (A16). *Ensure the cables are not pinched or damaged during installation*.

Attach the Stationary Handlebar on the Upright Post with 2 Screws (B41) and tighten.







(T03)Allen Wrench (M5)




(B41) Screw M8x25mm
2PC


11. Handlebar Installation

Insert Handlebar Right (A14) into Handrail Arm (A04)


Tighten with 2 Bolts (B28), 2 Curve Washers (B30) and 2 Nylon Nuts (B29)

Repeat this step for the left side.





(T01)Hex Tool with Phillips Screwdriver




(B28)Carriage Bolt M8

2 PCS



(B29)Nylon Nut M8x7.7T
2 PCS




(B30)Curve Washer
M8x20x1.5T 2PC


12. Computer Installation


Remove 4 Screws (B17) from the back of the Computer (D02)

Connect both wires from the Stationary Handlebar (A16) to the Computer. Use the 9 pin white socket port. Gently tuck the cables into the Stationary Handlebar and ensure the wires are not pinched.



Secure the computer to the Stationary Handlebar using the previously removed 4 screws.







(T01)Hex Tool with Phillips Screwdriver

13. Post Cover Installation

Attach the Post Cover (C07, C08) onto Upright Post (A02) with 2 Screws (B40)





(T01)Hex Tool with Phillips Screwdriver





(B40) Screw M5x16mm
2PCS

14. Handlebar Cover Installation

Attach Handlebar Covers (C17, C18) onto the Right Handrail Arm (A04) with 4 Screws (B40)

Repeat this step for the left side.






(T01)Hex Tool with Phillips Screwdriver




(B40) Screw M5x16mm
4PCS

15. Bottle Holder Installation

Remove the 2 Screws (B45) from Upright Post (A02) Attach the Bottle Holder (C27) onto the Upright Post with the removed screws.






(T01)Hex Tool with Phillips Screwdriver


16. AC Adaptor Installation

Connect the AC Adaptor (D08) to the AC Cable Plug (D09) on the front of the Main Frame (A01)



17. Adjusting the Foot Pads

Turn the Foot Pads (C05/C21) as necessary to ensure all 6 Foot Pads touch the floor. This will prevent the elliptical from wobbling during exercise and reduce noise.





BUTTON FUNCTION:

ON/OFF FAN	Turn the fan on or off
QUICK START STOP	To start or stop workout
UP/DOWN	To select training mode or adjust function value
RESET	In stop mode, press the button to return to main menu. Press and hold for 2 seconds to reboot the computer and reset all values to 0.
ENTER	Confirm setting or selection
RECOVERY	To test heart rate recovery level


DISPLAY FUNCTION

Function	DisplayRange	SettingRange	Unit
TIME	00:00~99:59	±1;00:00~99:00	Minutes
DISTANCE	0.0~99.99	±1;00:00~99:00	ML
CALORIES	0~9999	±10;00:00~9990	CAL
PULSE	30~230	±1; 30~230	BPM
SPEED	0.0~99.9	N/A	ML
RPM	0~999	N/A	RPM
WATT	0~999	±5; 10~350	W

OPERATING PROCEDURE

1.POWER ON/OFF –

After connecting the power, the console will power on with a long beep sound, LCD display all segments and then enter into User Profile set up mode. Console will enter sleep mode after 5 minutes of inactivity.



Quick Start - Press QUICK START to start exercise in MANUAL mode immediately without inputting any settings.

2.USER PROFILE



Press UP/DOWN to select User #



Press UP/DOWN to turn profile editing on or off
If you choose EDIT ON, you can edit the profile values below.



Use UP/DOWN and ENTER to input profile value of sex, age, height and weight.



The console needs your profiles to better calculate the workout values





3.WORKOUT SELECTION


In main menu, press UP/DOWN to scroll through MANUAL, PROGRAM (12 programs), USER PROGRAM, HRC and WATT. Press ENTER to confirm selection.

3.1. Manual mode

Before exercising in Manual mode, user can set up Time, Distance, Calories, and Pulse target and press ENTER to confirm. After set up of all the targets, press the START to start workout.

Resistance level can be adjusted during exercise by pressing UP or DOWN.

Press STOP to pause the workout reading, and you can press START to continue the workout. Press RESET to return to main page.




3.2. Program Mode

Press UP or DOWN to select between 12 different workout programs and then press ENTER to set up Target Time . Press START to start workout.

Resistance levels can be adjusted during exercise by pressing UP or DOWN.

Press STOP to pause the workout reading, and you can press START to continue the workout. Press RESET to return to main page.




3.3 User Program

User Program allows you to create your own workouts based on resistance level and time intervals.

Press UP and DOWN to create the profile, press ENTER to input additional resistance level, then press and hold ENTER for 2 seconds to exit profile setting. Press START to start work out.

Standard work out time is 20 minutes.

Press STOP to pause the workout reading, and you can press START to continue the workout. Press RESET to return to main page.



3.4. Heart Rate Control (HRC)


Input or select your user profile U1-U4. HRC will automatically adjust the machine's resistance levels to keep you at your selected target heart rate.

There are 4 target heart rate zones: 55%, 75%, 90% and TAG (allows you to set your own target heart rate); press UP and DOWN to select one program and press ENTER to set up exercise time. Press START to start workout.



If the console does not receive the pulse signal, the bottom LCD will show "Pulse Input" for reminder.


Press STOP to pause the workout reading, and you can press START to continue the workout. Press RESET to return to main page


TARGET HEART RATE ZONE
100%
Serious athletic training range
90%
Cardiovascular conditioning range
75%
Fat burning range
55%
200 195 190 185 180 175 170 165 160 155
170 166 162 157 153 149 145 140 136 132
150 146 143 139 135 131 128 124 120 116
120 117 114 111 108 105 102 99 96 93
20 25 30 35 40 45 50 55 60 65
AGE

3.5 WATT

Press UP and DOWN to setting WATT and Time target. Press START to start work out.

Press STOP to pause the workout reading, and you can press START to continue the workout. Press RESET to return to main page



4. Recovery: A fitness test which measures how quickly your heart rate returns to normal after exercising

After exercising press RECOVERY and place both hands on the handpulse. TIME starts counting down from 00:60 to 00:00.

Screen will display your heart rate recovery status with the F1,F2….to F6. F1 represents the fastest recovery time, F6 represents the slowest.

Press the RECOVERY button again to return to main display




Start Recovery Function



Test Result

5. Bluetooth Mode

Enable Bluetooth on your smart device, search for and connect to the console (name is on the back of the console). When your smart device is connected to the console, the Bluetooth symbol will appear on the LCD.




Please note:

1. Holding down the RESET button for 2 seconds will reset the console and your Bluetooth connection.

HEART RATE CHEST BELT





1. For the most accurate readings, the transmitter belt must have direct contact with the skin.

2. For accurate readings, stay within 4 feet of the computer.

3. The belt will send your pulse to the computer.

4. To change the battery use a flat head screwdriver or coin to turn the battery cap counter clockwise. Replace the dead battery with a new CR2032 3V battery. Replace the battery cover and turn clockwise to tighten.

5. You can check battery function without the computer by placing one hand on each sensor strip. The red light above the logo will flash.

TROUBLESHOOTING

Computer not working correctly
Check to make sure the computer cable is connected securely.
Check that the AC Adaptor is securely connected to the Power Supply Cable and to the electrical wall outlet.

The elliptical trainer wobbles or shakes when in use
Turn the adjustable leveler on the front stabilizer or U shape rail as needed to level the elliptical trainer.

Squeaking noise when in use
The bolts may be loose on the elliptical trainer. Inspect all bolts and tighten as needed. Thoroughly clean the Aluminum Rail (F01) of any dust and sweat.

No readings or inconsistent/erratic heart rate readings
Always hold on to the handlebar grip sensors with both hands instead of just one.
Try to maintain moderate pressure while holding onto the hand pulse sensors.
Make sure that the wire connections for the hand pulse sensors are secured.
Make sure to wipe sweat off hands.

MAINTENANCE

Cleaning
The elliptical trainer can be cleaned with a soft cloth and mild detergent. Do not use abrasives or solvents on plastic parts. Please wipe your perspiration off the elliptical trainer after each use. Be careful not to get excessive moisture on the computer display panel as this might cause an electrical hazard or electronics to fail. Please keep the elliptical trainer, especially the computer console, out of direct sunlight to prevent screen damage or premature wear. Please inspect all assembly bolts and pedals on the machine for proper tightness every week.

Storage
Store the elliptical trainer in a clean and dry environment away from children.

MANUFACTURER'S LIMITED WARRANTY

Paradigm Health & Wellness warrants to the original purchaser that this product is free from defects in material and workmanship when used for the purpose intended, under the conditions that it has been installed and operated in accordance with Paradigm's Owner's Manual. Paradigm's obligation under this warranty applies to the following:

COMPONENT	LENGTH OF WARRANTY
Frame	**Lifetime**
Normal Wearable Parts /Electronics	**2 years** (upholstery, brake, pads, foam grips, pedals etc…)
Labor and Other Parts	**5 years**

Exclusions from Warranty Coverage:

Paradigm does not warrant against and is not responsible for, and no implied warranty shall be deemed to cover, any product failure, product malfunction, or damages attributable to:

1. Improper installation and/or failure to abide by Paradigm's installation guidelines;
2. Use of this product beyond normal home use, or in an application for which it was not designed;
3. Cosmetic items such as scratches, dents or discolorations;
4. Damage caused by normal wear and tear, vandalism, accidental or by animals;
5. Any act of Nature (such as fire, flooding, snow, ice, hurricane, earthquake, lightning or other natural disaster), environmental condition (such as air pollution, mold, mildew, etc.), or staining from foreign substances (such as dirt, grease, oil, etc.);
6. Normal weathering due to exposure to sunlight, weather and atmosphere which can cause colored surfaces to, among other things, flake, chalk, accumulate dirt or stains.
7. Improper operation, alteration, handling, storage, abuse or neglect of the products.

Paradigm, using its sole discretion, will either repair or replace free of charge any part(s) proven to be defective under normal home use. Any repair or replacement shall provide no new warranty coverage, but shall retain only the remaining portion of the original product's warranty. This warranty is offered only to the ORIGINAL purchaser and is not transferable. Proof of original purchase is required.

Ordering Replacement Parts

For best service, please email our customer service department:

Service@paradigmhw.com

Response Time: 1-2 Business Days

Or call toll free at 1-844-641-7922. Daily 8:00 AM - 5:00 PM (PST).
Response Time may vary.

When ordering replacement parts please have the following information ready:

1. Owner's Manual
2. Model Number
3. Description of Parts
4. Part Number
5. Date of Purchase


Quadriceps Stretch
With one hand against a wall for balance, reach behind you and pull your right foot up. Bring your heel as close to your buttocks as possible. Hold for 15 counts and repeat with left foot up.



Inner Thigh Stretch
Sit with the soles of your feet together with your knees pointing outward. Pull your feet as close to your groin as possible. Gently push your knees towards the floor and hold for 15 counts.



Toe Touching
Slowly bend forward from your waist, letting you back and shoulders relax as you stretch toward your toes. Reach down as far as you can and hold for 15 counts.



Hamstring Stretch
Sit with your right leg extended. Rest the sole of your left foot against your right inner thigh. Stretch toward your toe as far as possible. Relax and hold for 15 counts. Repeat with left leg extended.



Paradigm Health & Wellness, Inc.

PARTS REQUEST FAX FORM

Please fax this form to (1-626-810-2166)

OR YOU CAN EMAIL CUSTOMER SERVICE REQUESTS TO

service@paradigmhw.com

NAME: _____

ADDRESS: _____

CITY _____ **STATE** _____ **ZIP** _____

TELEPHONE: (Day) _____

(Night) _____

(Email Address) _____

SERIAL#: _____

MODEL#: _____

PURCHASE DATE: _____

PURCHASE FROM: _____

PART #	DESCRIPTION/REASON	QTY

"YOUR ORDER WILL BE PROCESSED WITHIN 3 BUSINESS DAYS"

OFFICIAL USE ONLY

SHIP DATE: _____

TRK #: _____

BACK ORDER: _____