


IRONKIDSTM fitnessplayground



PLAYGROUND MIST

ITEM NO: 8901



Mist hose can be used on IronKids
playgrounds or other swing sets.

OWNER'S MANUAL



IMPORTANT:

Read all instructions carefully before using this product. Retain this owner's manual for future reference. The specifications of this product may vary from this photo, subject to change without notice.



PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE.

STOP. Contact customer service if you have any questions regarding assembly or proper operation of the machine.

Email us at:
Service@paradigmhw.com

Or call us at:
1-844-641-7922
Hours:
8:00 am to 5:00 pm (PST) Daily

TABLE OF CONTENT

SERVICE-----	2
IMPORTANT SAFETY GUIDELINES-----	3
HARDWARE PACK-----	4
ASSEMBLY-----	5
WARRANTY-----	6
PARTS REQUEST FORM-----	7

SERVICE

IMPORTANT: FOR NORTH AMERICA ONLY

For damaged or defective product, questions, replacement parts or any other service support, please contact our customer service department (8:00 AM - 5:00 PM Pacific Standard Time, Daily) by the below methods:

For The Best Service, please Email:
service@paradigmhw.com

Response Time: 1-2 Business Days

Emailing us with the information above will be the best method to receive a response during peak business hours

Website:

www.paradigmhw.com

Toll-Free:

1-844-641-7922

Response time may vary via calling

Refer to our email for the best response time

Please have the following information ready when requesting for service:

- Your name
- Phone number
- Model number
- Serial number
- Part number
- Proof of Purchase

For damaged or defective product please contact our customer service before returning to the store.

Paradigm Health & Wellness, Inc.

1189 Jellick Ave.

City of Industry, CA 91748, USA

IMPORTANT SAFETY GUIDELINES

Read all instructions carefully before assembling operating this product. Retain this owner's manual and keep the original purchase receipt for future reference.

1. To prevent serious injury, do not allow children to play the Playground Mist Hose until it is completely installed.
2. Only adults should assemble or disassemble this Playground Mist Hose.
3. Teach and instruct children not to pull the Playground Mist Hose off from the frame.
4. Warn children not to use the equipment in any manner other than intended.
5. Do not place any part of the body near moving parts.
6. Ensure that the Playground Mist Hose is secured on the frame.
7. Do not use the Playground Mist Hose before reading manual.

⚠WARNING: Before beginning any exercise program consult your physician.

This is especially important for the people who are over 35 years of age or who have pre-existing health problems. Read all instructions before using any fitness equipment.

⚠CAUTION: Read all instructions carefully before operating this product.


Retain this Owner's Manual for future reference.

CARE AND MAINTENANCE

Check all bolts by monthly during the usage season for tightness and tighten as required. It is particularly important that all bolts are checked prior to the first use each season.






TOOL REQUIRED FOR ASSEMBLY

Please prepare the following tool prior to assemble this equipment.




Phillips Screwdriver
(not Included)

HARDWARE PACK

A		Mist Hose	1 PC
B		Mist Hose Nozzle with On/Off Switch	1 PC
C		Mist Holder	4 PCS
D		Bolt	4 PCS
E		Velcro Strap	3 PCS

ASSEMBLY



Route the Mist Hose (A) as illustrated.

1. Install one **Mist Holder (C)** onto the left end of the mist spout on the **Mist Hose (A)**. Then attach the **Mist Holder (C)** with **Mist Hose (A)** onto the top bar with one **Bolt (D)** as showed in detailed drawing. Tighten **Bolt (D)** with the **Phillips Screwdriver**.
2. Install the second **Mist Holder (C)** onto second mist spout on the **Mist Hose (A)**. Then attach the second **Mist Holder (C)** with **Mist Hose (A)** onto the top bar with one **Bolt (D)**. Tighten **Bolt (D)** with the **Phillips Screwdriver**.
3. Install the third **Mist Holder (C)** onto third mist spout on the **Mist Hose (A)**. Then attach the third **Mist Holder (C)** with **Mist Hose (A)** onto the top bar with one **Bolt (D)**. Tighten **Bolt (D)** with the **Phillips Screwdriver**.
4. Install the fourth **Mist Holder (C)** onto fourth mist spout on the **Mist Hose (A)**. Then attach the fourth **Mist Holder (C)** with **Mist Hose (A)** onto the side leg with one **Bolt (D)**. Tighten **Bolt (D)** with the **Phillips Screwdriver**.
5. Secure the **Mist Hose (A)** to the top bars and side leg using the three Velcro straps provided and Velcro straps on the Protective Net as illustrated.
6. Connect the **Mist Hose Nozzle with On/Off Switch (B)** to the **Mist Hose (A)** by turning it in a clockwise direction.
7. Connect a water hose to the **Mist Hose Nozzle with On/Off Switch (B)**.

WARRANTY

MANUFACTURER'S LIMITED WARRANTY

Paradigm Health & Wellness warrants to the original purchaser that this product is free from defects in material and workmanship when used for the purpose intended, under the conditions that it has been installed and operated in accordance with Paradigm's Owner's Manual. Paradigm's obligation under this warranty applies to the following:

COMPONENT LENGTH OF WARRANTY

Structural Frame Lifetime

All Other Components 180 days

(console display, electronics, upholstery, foam, ball bearings, pulleys, belts, cables, wires, shocks, covers, tension, internal mechanism, wheels, pedals, knobs, accessories and hardware)

Exclusions from Warranty Coverage:

Paradigm does not warrant against and is not responsible for, and no implied warranty shall be deemed to cover, any product failure, product malfunction, or damages attributable to:

1. Improper installation and/or failure to abide by Paradigm's installation guidelines;
2. Use of this product beyond normal home use, or in an application for which it was not designed;
3. Cosmetic items such as scratches, dents or discolorations;
4. Damage caused by normal wear and tear, vandalism, accidental, and by animals;
5. Any act of Nature (such as fire, flooding, snow, ice, hurricane, earthquake, lightning or other natural disaster), environmental condition (such as air pollution, mold, mildew, etc.), or staining from foreign substances (such as dirt, grease, oil, etc.);
6. Normal weathering due to exposure to sunlight, weather and atmosphere which can cause colored surfaces to, among other things, flake, chalk, accumulate dirt or stains.
7. Improper operation, alteration, handling, storage, abuse or neglect of the products.

Paradigm, using its sole discretion, will either repair or replace free of charge any part(s) proven to be defective under normal home use. Any repair or replacement shall provide no new warranty coverage, but shall retain only the remaining portion of the original product's warranty. This warranty is offered only to the original purchaser and is not transferable.

Proof of original purchase is required.

Ordering Replacement Parts

Replacement parts can be ordered by emailing our customer service department:

Service@paradigmhw.com

Open Daily 8:00 AM - 5:00 PM (PST).

When ordering replacement parts please have the following information ready:

- 1. Owner's Manual**
- 2. Model Number**
- 3. Description of Parts**
- 4. Part Number**
- 5. Date of Purchase**

PARTS REQUEST FORM

Paradigm Health & Wellness, Inc.

EMAIL THIS FORM WITH YOUR RECEIPT OF PURCHASE TO

Service@paradigmhw.com *

NAME: _____

ADDRESS: _____

CITY: _____ STATE: _____ ZIP: _____

TELEPHONE: (Day) _____

(Night) _____

SERIAL#: _____

MODEL#: _____

PURCHASE DATE: _____

PLACE OF PURCHASE: _____

PART #	DESCRIPTION	QTY

“YOUR ORDER WILL BE PROCESSED WITHIN 3 BUSINESS DAYS”

**** This form can also be faxed in Fax #: 626-810-2166***