


PLAYGROUND MIST ITEM NO: 8902



OWNER'S MANUAL

The specifications of this product may vary from this photo and are subject to change without notice. IRONMAN, IRONMAN TRIATHLON and M-DOT are registered trademarks of World Triathlon Corporation. This product is licensed by the IRONMAN TRIATHLON.

IMPORTANT: FOR NORTH AMERICA ONLY To request product service and order replacement parts, please call our customer service department at:

1-866-924-1688

Monday through Friday, 8:00 AM-5:00 PM Pacific Standard Time,

or email us at: Service@paradigmhw.com

Please visit our website at www.paradigmhw.com.

Please have the following information ready when requesting for service:

Your name
Phone number
Model number
Serial number
Part number

Proof of Purchase

*Before returning this product to the store please contact customer service at the contact number.

Paradigm Health & Wellness, Inc. 1189 Jellick Ave. City of Industry, CA 91748, USA

TABLE OF CONTENTS

Warranty	- 3
Important Safety Precautions	- 4
Tool Required for Assembly	- 4
Package Contents	- 5
Assembly Instructions	- 6
Parts Request Fax Form	- 7

MANUFACTURER'S LIMITED WARRANTY (IRONKIDS FITNESS PLAYGOUND)

Paradigm Health & Wellness warrants to the original purchaser that this product is free from defects in material and workmanship when used for the purpose intended, under the conditions that it has be installed and operated in accordance with Paradigm's Owner's Manual. Paradigm's obligation under this warranty applies to the following:

COMPONENTLENGTH OF WARRANTYStructural FrameLifetime (1)All Other Components180 days (2)

This warranty does not include damage caused by normal wear and tear, weather corrosion, misuse, commercial use or improper operation. Paradigm will replace free of charge any parts which may prove to be defective under normal home use. This warranty is offered only to the original purchaser and is not transferable. Proof of original purchase is required.

Ordering Replacement Parts

Replacement parts can be ordered by calling or emailing our customer service department service@paradigmhw.com

1-866-924-1688

Monday through Friday, 8:00 AM - 5:00 PM (PST).

When ordering replacement parts please have the following information ready:

- 1. Owner's Manual
- 2. Model Number
- 3. Description of Parts
- 4. Part Number
- 5. Date of Purchase

IMPORTANT SAFETY PRECAUTIONS

Read all instructions carefully before assembling operating this product. Retain this owner's manual and keep the original purchase receipt for future reference.


- To prevent serious injury, do not allow children to play the Playground Mist Hose until it is completely installed.
- 2. Only adults should assemble or disassemble this Playground Mist Hose.
- 3. Teach and instruct children not to pull the Playground Mist Hose off from the frame.
- 4. Warn children not to use the equipment in any manner other than intended.
- 5. Do not place any part of the body near moving parts.
- 6. Ensure that the Playground Mist Hose is secured on the frame.
- 7. Do not use the Playground Mist Hose before reading manual.

CARE AND MAINTENANCE

Check all bolts by monthly during the usage season for tightness and tighten as required. It is particularly important that all bolts are checked prior to the first use each season.

TOOL REQUIRED FOR ASSEMBLY

Please prepare the following tool prior to assemble this equipment.




Phillips Screwdriver (not Included)

PACKAGE CONTENTS

А	Mist Hose	1 PC
В	Mist Hose Nozzle with On/Off Switch	1 PC
С	Mist Holder	4 PCS
D	Bolt	4 PCS
E	Velcro Strap	3 PCS

ASSEMBLY INSTRUCTIONS



Route the Mist Hose (A) as illustrated.

- 1. Install one Mist Holder (C) onto the left end of the mist spout on the Mist Hose (A). Then attach the Mist Holder (C) with Mist Hose (A) onto the top bar of the climbing net with one Bolt (D) as showed in detailed drawing. Tighten Bolt (D) with the Phillips Screwdriver.
- 2. Install the second Mist Holder (C) onto second mist spout on the Mist Hose (A). Then attach the second Mist Holder (C) with Mist Hose (A) onto the top bar of the roundabout with one Bolt (D). Tighten Bolt (D) with the Phillips Screwdriver.
- 3. Install the third Mist Holder (C) onto third mist spout on the Mist Hose (A). Then attach the third Mist Holder (C) with Mist Hose (A) onto the top bar of the swing set with one Bolt (D). Tighten Bolt (D) with the Phillips Screwdriver.
- 4. Install the fourth Mist Holder (C) onto fourth mist spout on the Mist Hose (A). Then attach the fourth Mist Holder (C) with Mist Hose (A) onto the side leg with one Bolt (D). Tighten Bolt (D) with the Phillips Screwdriver.
- 5. Secure the Mist Hose (A) to the top bars and side leg using the three Velcro straps provided and Velcro straps on the Protective Net as illustrated.
- 6. Connect the Mist Hose Nozzle with On/Off Switch (B) to the Mist Hose (A) by turning it in a clockwise direction.
- 7. Connect the house water hose to the Mist Hose Nozzle with On/Off Switch (B).

IRONKIDS

PARTS REQUEST FAX FORM

Please fax this form to (1-626-810-2166)

OR YOU CAN EMAIL CUSTOMER SERVICE REQUESTS TO

service@paradigmhw.com

NAME:			
ADDRESS:	STATE		
CITY	STATE	ZIP	
TELEPHONE: (Day) _			
(Night)			
	Address)		
	_#:		
MODEL	_#:		
PURCHASE DATE:			
PURCHASE FROM:			
PART#	PART # DESCRIPTION		QTY
			,
"YOUR ORDER WILL BE P	ROCESSED WITHIN 3 BUSINESS DA	YS"	
OFFICIAL USE ONLY			
SHIP DATE:			